

User manual

Optimus  
Bluetooth Headset

### **User's Manual**

Congratulations on your new ifidelity Optimus Bluetooth Headset!

Read carefully and follow all instructions in this User's Manual before you use the Optimus Bluetooth Headset.

Keep this User's Manual in a convenient location for future reference.

### **Safety Information**

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in electric shock or fire. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- Avoid contact with liquids and keep out of damp areas
- Avoid contact with intense heat
- Charge headset fully before use

### **Repairs:**

This unit should only be serviced by qualified service personnel, if:

- The unit has been exposed to liquids
- The unit has been dropped or the housing is damaged
- The unit exhibits a marked change in performance or does not operate normally.

Do not attempt to repair the unit yourself. Seek assistance from a qualified professional.

### **Periods of Non Use:**

If the unit is to be left unused for a period of 3 weeks or more, it is advised that the unit be charged to avoid damaging the internal lithium battery.

### **Headset Controls:**

1. Volume (press, hold)/Track Selection (press) (Pairing mode LED indicator between volume controls)
2. Volume (press, hold)/Track Selection (press) (Pairing mode LED indicator between volume controls)
3. On/Off, Play/Pause/Phone Calls (answer/reject)
  - On/Off: Press and hold to turn power on/off (Enters pairing mode automatically)
  - Play/Pause/Phone Calls: Press to play/pause music. Press to receive a call. Press button again or press and hold to end or ignore the incoming call.
4. 3.5mm Line-in Port (Cable included)
5. Micro-USB Charging Port (Cable included)
6. Microphone

### **User Instructions:**

Pairing:

- Press and hold the On/Off button. Audio prompt will sound: "Power On."
- Using your Bluetooth enabled device, search for available Bluetooth devices in range.
- Select "ifidelity Optimus" and follow the instructions on your device.
- Audio prompt will sound, "Connect me", indicating that the device was paired successfully.

To unpair: (2 options)

- 1: Unpair the devices from your Bluetooth device.
- 2: Press and hold the On/Off button. Audio prompt will sound: "Power Off."

\* Headphones may pair again when turned back on. This can be resolved by using your device to unpair the Optimus Bluetooth Headset.

\* A 3.5mm audio cable is included for devices that do not support Bluetooth connections.

**User Instructions:**

Headset can only support a single Bluetooth connection at a time. If experiencing trouble connecting, ensure that the Optimus Bluetooth Headset is not connected to another Bluetooth device. If this is the case, unpair it from the other device and try again.

Charging Built in Lithium Ion Battery :

Insert the Micro USB cable (included) into the headset port ( ). Insert the USB plug into a computer or power adapter.

When charging, the red indicator will illuminate.

The blue indicator will illuminate to indicate a full charge.

\* The headset should be turned off during charging.

CAUTION: DO NOT expose to intense heat, fire, or liquids.

**Troubleshooting:**

Issue

Not charging

No sound

No audio signal via Bluetooth connection

Speaker cannot be connected

Poor sound quality from Bluetooth device

Cause

The USB power adapter (not included) is not plugged into a wall socket or the USB cable (included) is not plugged into the mini USB jack on the bottom of the Optimus.

Wall socket is not functioning.

Computer USB port is not functioning.

Optimus battery is dead.

Optimus is not connected to/paired with the mobile phone or BT device.

Volume is too low.

Speaker is not paired to the audio source.

Volume is too low.

Pairing does not work.

Audio source is switched off.

Bluetooth is switched off at the audio source.

Bluetooth version is not supported.

Bluetooth device is out of range of the Optimus.

Solution

Plug the USB power adapter into a wall socket and plug the USB cable (included) into the mini USB jack on Optimus.

Plug another device into the same socket to confirm the socket is working.

Make sure your computer is turned on and try another USB port.

Recharge the Optimus's battery.

Follow the speaker instructions to connect the speaker.

Increase the volume of your device.

Check whether a connection exists. If necessary, pair the speaker with the audio source again.

Increase the volume on the speaker.

Increase the volume on the audio source.

Check whether the audio source supports Bluetooth connections.

Turn on the audio source.

Turn on the Bluetooth function for the audio source.  
Use a different playback unit.  
Move your Bluetooth device closer to the Optimus.

**Care and Maintenance:**

Do not subject the unit to excessive force, shock, dust or extreme temperatures.  
Do not tamper with the internal components of the unit.  
Clean the unit with a clean, dry cloth.  
Avoid leaving the unit in hot, humid or dusty places.  
Keep the unit away from heating appliances and sources of electrical noise such as fluorescent lamps and engines.  
Always ensure your finger is dry and clean before touching buttons.  
Do not dispose of the batteries in fire; the batteries may explode or leak.

**Included:**

- ifidelity Optimus Bluetooth Headset
- 3.5mm Line-in audio cable
- USB - micro USB charging cable
- Operating Instructions
- Storage Case

**Specifications:**

Battery Capacity (included):	350mAh
Charging Voltage:	DC 5V, 500mA and above
Max Playback Time:	8-12 hours at 50% vol.
Working Temperature:	-41°F~+ 100°F (-40°C – 37.8°C)
Charging Time:	2-4 hours

The right to make technical and design modifications in the course of continuous product development is reserved. This device has been tested according to all relevant and current guidelines, such as electromagnetic compatibility guidelines and low voltage directives, and has been constructed in accordance with the latest safety regulations.

ASSEMBLED IN CHINA

NOTES: