

USER'S MANUAL

experience originality *

Swerve
Bluetooth NFC speaker

INTRODUCTION

User's Manual

Congratulations on your purchase of the new ifidelity Swerve NFC Bluetooth speaker! Please read and follow all of the instructions in this User's Manual before using the Swerve Bluetooth speaker. Keep this User's Manual in a convenient location for future reference.

Safety Information

This unit has been designed and manufactured not to endanger your personal safety when properly used. However, improper use can potentially result in electrical shock or fire hazards. Please read all of the safety instructions and follow all of the operating instructions carefully before installation and use, and keep these instructions at hand for future reference. Take special notice of all warnings listed in these instructions and on the unit.

- Avoid contact with liquids and damp surfaces
- Do not block the ventilation openings
- Fully charge the battery before use

NOTES:

NOTES:

If damaged:

This unit should be serviced by qualified service personnel only when:

- The unit has been exposed to liquids.
- The unit has been dropped or the enclosure has been damaged.
- The unit exhibits a marked change in performance or is not operating normally.

Do not attempt to service the unit yourself. Seek assistance from a qualified professional.

During periods of non-use:

If the unit is not being used for a period of 1 week or more, unplug the power cord from the unit in order to prevent damage or corrosion.

Speaker Controls:

NOTES:

Specifications:

Battery (included) capacity :	700 mAh
Charging Voltage:	DC 5V, 500mAh or higher
Max. Playing Time:	3 Hours
Operating Temperature:	-41°F to +100°F
Operating Humidity:	20% to 80%

We reserve the right to make technical and design modifications in the course of our continuous product development. This device has been tested according to all current and relevant CE guidelines, such as its electromagnetic compatibility and low voltage directives, and this unit has been constructed in accordance with the latest safety regulations.

ASSEMBLED IN CHINA

1. Built-in Microphone
 2. “-“ Button:
 - In Bluetooth mode :
Press to decrease volume level
 3. **H** Button
 - In Bluetooth mode:
Press once to play or twice to pause
 - In Bluetooth mode:
Press once to receive a call
Press button again or press and hold to
end or ignore an incoming call
 4. “+“ Button
 - In Bluetooth mode :
Press to increase volume level
 5. Battery charging indicator (Red)
 - Rapid flashing = low batteryWhile charging:
 - Flashing red light = charging
 - Steady red light = fully charged
-
6. Operating Mode Indicator (Red/Blue/Purple)
 - Blue = Bluetooth mode
 - Red = Aux-In mode
 7. Mini USB charging port
 8. Aux-In jack
 9. Power ON/OFF
 10. NFC Contact Area

Charging the battery:

The built-in Li-ion battery can be recharged via a USB port on your computer or a USB power adaptor (not included) with a rated output of DC 5V 500mAh or higher.

NOTE: The mini USB charging device connected on this unit is only designed for charging the unit.

When charging the battery for the first time:

1. Charge the built-in Li-ion battery for a minimum of 2 hours prior to first use. Plug the unit into a USB port on your computer or into a USB power adaptor (not included) using the USB cable included.
2. The battery charging indicator light will flash while charging and will stop flashing when the unit is fully charged.

Unplug the USB cable from the power source once the battery is fully charged.

CAUTION: Only replace the battery with the same type or an equivalent.

DO NOT expose the battery to intense heat, flame, or liquids.

Care and Maintenance:

Do not subject the unit to excessive force, shock, dust or extreme temperatures.

Do not tamper with the internal components of the unit.

Clean the unit with a clean, dry cloth. Avoid leaving the unit in hot, humid or dusty places.

Keep the unit away from heating appliances and sources of electrical noise, such as fluorescent lamps or motors.

Make sure your hands are dry and clean before touching the control buttons.

Do not dispose of the batteries in fire; they may explode or leak.

User Instructions:

Slide the Power ON/OFF selector on the bottom of the unit to the ON position. A voice prompt and a tone will sound. The Operating Mode Indicator will flash blue.

To pair using NFC:

If the compatible device supports NFC, activate its NFC feature.

Touch the NFC area of the speaker while the speakers are in pairing mode. A voice prompt and a tone will sound, and the blue indicator will stop flashing.

* If the device does not support NFC, pair the speaker manually.

Manual pairing:

1. Turn the speaker on. The Operating Mode Indicator will flash blue when the unit is ready to pair.
 2. Activate the Bluetooth settings on your device and search for compatible devices.
-

3. Select the speaker name "Swerve" from the list of devices found.

4. If your device asks for a passkey, enter "0000" (four zeros) and press OK.

If pairing has been successful, a voice prompt and a tone will sound. The blue indicator light will also stop flashing.

NOTE: Only one device at a time can be connected to the speaker. If paired with another device, "Swerve" will not appear on the list of available devices.

Using the Swerve speaker as a conference call phone:

1. Pair your cellular phone to the Swerve speaker as described above.
2. To receive an incoming call, tap the **H** button. A tone will sound to confirm that the call is being received. Conference your call using the built-in microphone/speaker.
3. Adjust the volume controls of your cellular phone to the desired level.

Poor sound quality from Bluetooth device	Bluetooth device is almost out of range of the Swerve speaker	Move your Bluetooth device closer to the Swerve speaker
--	---	---

No audio signal via Bluetooth connection	Speaker is not paired with the audio source	Check if there is still a connection. If necessary, pair the speaker again with the audio source device. _____
	Volume is too low	Increase the volume on the speaker / Increase the volume on the audio source
Speaker cannot be connected	Pairing does not work	Check whether the audio source supports the A2DP protocol
	Audio source is turned off	Turn on the audio source
	Bluetooth is turned off at the audio source	Turn on the Bluetooth function in the audio source
	Bluetooth version is not supported.	Use a different playback unit.

4. To end a call, press the **H** button again. A tone will sound to indicate the call has been ended. If the speaker was being used prior to this call, audio playback will automatically resume when the call ends.
5. To ignore an incoming call, press and hold the **H** button for approx. 2 seconds. A tone will sound to indicate that the call has been ignored.

Operating in microSD Card Mode:

1. Insert a microSD card. The LED indicator will turn purple when ready.
 2. Press the **H** button to pause or resume playback.
 3. Press and hold the "+" or "-" buttons to adjust the volume.
 4. Briefly press the "+" button to fast-forward to the next track or press the "-" button to rewind to the previous track.
 5. Pause the unit when removing the microSD card from its slot.
- * Turn the speaker off when finished.

Operating the Swerve speaker in Aux-In Mode:

1. Plug one end of the 3.5mm audio cable (included) into line-out jack on your player. Plug other end of cable into the AUX-IN jack on the Swerve speaker.
2. Select 'external audio source' to play from your device.
3. Set power to ON and the Operating Mode Indicator light will light up Red.
4. The volume levels can now be controlled through the main speaker unit. Operate all the other functions on the external device as you normally would.

Troubleshooting:

Issue	Cause	Solution
-------	-------	----------

Not Charging	The USB power adaptor (not included) is not plugged into a wall socket or the USB cable (included) is not plugged into the mini USB plug on the bottom of the Swerve speaker	Plug the USB power adaptor (not included) into a wall socket and plug the USB cable (included) into the mini USB plug on the Swerve speaker
	Wall socket is not functioning	Plug another device into the same outlet to check that the outlet is working
	Computer USB port is not functioning	Make sure your computer is turned on and try another USB port.
No Sound	The Swerve speaker's battery is empty	Recharge the Swerve speaker's battery
	The Swerve speaker is not connected to a cellular phone	Go through the operating instructions again to link the speaker
	Volume level is set too low	Increase the volume on your device.